

Adding/Deleting User Codes

**NOTE: To Delete a user code enter the Master/Partition Programmer code + [8] + User # (03-49) + [#] [0]**

**NOTE: User 02 is the master code & its attributes cannot be changed.**

**User 03 is defaulted as P1 Programmer**

**User 04 or 33 is defaulted as P2 Programmer based on revision of panel**

- 
1. Enter the Master/Partition Programmer Code + [8] + User Number (03-49) + New Code  
NOTE: This can be done from any partition

---

  2. Keypad will beep 1 time for confirmation letting you know the code was successfully entered.

---

  3. Enter the Master/Partition Programmer Code + [8] + User Number used in step 1 + [#] [1] + Authority Level  
0=Standard User, can arm/disarm/bypass  
1=Arm Only, Can only arm the system  
2=Guest, Can arm the system in assigned partition, but cannot disarm the system unless it was armed with this code  
3=Duress Code, Sends a silent signal to CS when arming/disarming  
4=Partition Programmer, Can do everything a standard user can do, & assign user codes for users In their partition

---

  4. Keypad will beep 1 time for confirmation letting you know the code was successfully entered.

---

  5. If partitioning enter the Master/Partition Programmer code + [8] + User number used in step 1 + [#] [3] + The partition # (1-3) + [#].  
Partition #'s:  
0=Clears Part. 1 & 2 assignments  
1=Partition 1  
2=Partition 2  
3=Common Partition

---

  6. Keypad will beep 1 time for confirmation letting you know the code was successfully entered.

---

  7. If this user is to be sent to the pager enter the Master/Partition Programmer Code + [8] + User Number used in step 1 + [#] [5] + 1  
0=No paging for this user  
1=Paging allowed for this User

---

  8. Keypad will beep 1 time for confirmation letting you know the code was successfully entered.

---

  9. If this user is to be assigned to an RF Button enter the Master/Partition Programmer Code + [8] + User number used in step 1 + [#] [4] + the RF button Zone Number

---

  10. The keypad will beep 1 time for confirmation letting you know the code was successfully entered.
-